

Scottoiler



With the CB1300 attach the vacuum connection on the right side at the fourth cylinder, as shown in the photograph on the left.

The thin vacuum hose runs between the carburetors through to the rear. RMV positioned as shown below, left, under seat at rear.



Dispenser position as shown, in the two pictures below. NB: Usual dispenser position is onto sprocket with 45degree cut facing outwards as per next picture.

